


Register your product
and get support at
www.philips.com/welcome

SRC2063/27




EN User Manual

PHILIPS



SRP2006/27

For an overview of the buttons and their functions refer to chapter 3.1.



SRP2003/27

Table of contents

1	Your SRC2063	3-4
2	Getting started	4-8
	2.1 Inserting the batteries	4
	2.2 Setting up the universal remote controls	4-8
3	Using the universal remote controls... 9-11	
	3.1 Buttons and functions	9-10
	3.2 Resetting a button to its original function	11
4	Service and support	12-15
	4.1 Frequently asked questions	12-14
	4.2 Need help?	14
	FCC Compliancy	15
	Notice for Canada	16
	Helpline	17
	Brand list	18-30
	Information to the consumer	31
	Compliance with EMF	31
	Recycling and disposal	

1 Your SRC2063

Congratulations on your purchase of the Philips SRC2063 universal remote control twinpack. The pack contains the 3-device remote control SRP2003 and the 6-device remote control SRP2006. After setting up the remote controls you can operate up to 3 different devices with the SRP2003 and up to 6 different devices with the SRP2006.

Simple Setup

Both universal remote controls come with the innovative Simple Setup technology. After setup, the remote controls can operate TV, DVD player / recorder (including Blu-ray player) and all common Cable, Satellite, DTV and other set top boxes, such as DirecTV, Comcast, AT&T, Verizon, Time Warner, Scientific Atlanta, Tivo and many more. The SRP2006 can also be set up for VCR, and DVR.

Simply follow the instructions in chapter 2.2 to set up the remote controls for your devices.

Glow buttons (SRP2006 only)


The SRP2006 glow buttons: (ENTER, (-) and the numeric buttons) glow in the dark, enabling easy use of the remote control, even in a dimly lit room.

To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

2 Getting started

2.1 Inserting the batteries

- Insert 2 AAA type batteries, noting the + and - configuration in the battery compartment.



Note

When replacing the batteries, all user settings will be retained in the remote control memory for 5 minutes.

2.2 Setting up the universal remote controls

The example below instructs you how to set up your universal remote controls for your TV. You can repeat the same steps for other devices (DVD player / recorder; DTV, Cable / Satellite box, DVR and VCR) which you want to operate, using the universal remote controls.


Note

The setup procedure is the same for both remote controls.

The remote controls can be set up to operate any 3 or 6 of the following devices:

Device name	Description
TV	Traditional TV, LCD / Plasma TV and projection TV, TV part of TV / VCR, TV / VCR / DVD and TV / DVD combos
DVD	DVD player / recorder (DVDR), DVD / Hard Disk Drive combination (DVDR-HDD), Blu-Ray player; High Definition DVD player (HD-DVD), DVD part of TV / DVD, TV / VCR / DVD and VCR / DVD combos
CBL/SAT	Cable box, satellite receiver; Internet Protocol TV (IPTV), Free To Air TV, High Definition Television decoder (HDTV), Digital Television (DTV) and Tivo
VCR (SRP2006 only)	Video cassette player / recorder; VCR part of TV / VCR, TV/VCR/DVD and VCR/DVD combos
DVR (SRP2006 only)	Digital / Personal Video Recorder (DVR / PVR), Tivo

Example: setting up the universal remote controls to operate your TV:

- Switch ON the TV manually or use the original remote control for this. Tune to channel 1.
- Press and hold the TV device selection button for 5 seconds until the red Setup light  blinks. The remote control is now in setup mode.




- 3 Look up the 4-digit code for your brand in the brand list at the back of this user manual.





A 4-digit code is shown for each brand.

Use the digit buttons to enter the code for your brand.

- If the red Setup light  turns off, an invalid code was entered. In this case, try again.




- 4 Aim the remote control at the TV. **Press and hold** the  button. Release it **immediately** as soon as the TV switches off.




- This step normally takes between 5 and 60 seconds. In extreme circumstances this step can take up to 15 minutes.

- 5 **Switch ON** the TV. Try out the buttons that you need for operating it. Try, for example, if the - CH + and digit buttons function properly.



- If a button does not work as expected, **press and hold** that button. Release it **immediately** as soon as it works. For more information, see chapter 2.2.2.


- 6 Press the  device selection button **twice** to finish setup.



- When no button is pressed for 5 minutes or more, the remote control will exit setup mode, automatically saving all your settings.








! Important

If you made a mistake:

- Press the device selection button **twice** to exit setup. The red Setup light  turns off.
- Restart from the beginning.

- *If the device does not respond at all or not to all of the button commands or if you cannot find the code for your brand, enter '9, 9, 9, 9' in step 3 and continue with step 4. The remote control will now search its full database for a code that works with your TV. Full database search may take up to 15 minutes.*

2.2.1 Setting up the remote controls for other devices (DVD player / recorder; DTV, Cable / Satellite box, DVR and VCR)

- 1 Make sure the device is switched on and operational. E.g. insert a disc in the DVD player / recorder or a video cassette in the VCR (SRP2006 only).
- 2 Then follow steps 2 to 6 of 'Setting up the universal remote controls to operate your TV'. Make sure to use the correct device selection button:
 - for SRP2003:  or .
 - for SRP2006: , , ,  or .

2.2.2 Improving buttons

When correctly set up, the remote control should be able to operate all your devices. However, when using the remote control for the first time it might occur that some buttons do not yet function as expected. In this case you can have the remote control search for alternatives.

≡ Note



Improving buttons is not possible when the code was found during full database search (with code '9, 9, 9, 9').

During initial setup

- 1 Make sure the receiving device is able to respond. E.g. when you try to repair the Play button for your DVD player; make sure to insert a DVD into the DVD player otherwise the Play button is not able to function.
- 2 Press the button that does not function, keep it pressed and **immediately** release it when the device responds. Repeat this for every button that does not function.
 - If the button still does not function as expected, try pressing it again for a longer period of time.


After initial setup


- 1 Make sure the receiving device is able to respond. E.g. when you try to repair the Play button for your DVD player; make sure to insert a DVD into the DVD player otherwise the Play button is not able to function.

- 2 Select the device that you wish to operate (e.g. DVD). Press the  or  device selection button to select DVD.





- 3 Keep buttons ① and ④ pressed simultaneously for 5 seconds.



- The red Setup light  lights up. The remote control is now in setup mode.

- 4 Press and hold the button that does not function and **immediately** release it when the device responds.

- If the button still does not function as expected, try pressing it again for a longer period of time.

- 5 Press the  or  selection button **twice** to save your settings and exit setup mode.



- When no button is pressed for 5 minutes or more, the remote control will exit setup mode, automatically saving all your settings.




3 Using the universal remote controls


3.1 Buttons and functions










The illustrations on page 2 gives an overview of all buttons on the remote controls. Try out the buttons you need for operating your devices.

 Notes


- Buttons having the same functions as the buttons on your original remote control may have different namings on the SRP2003 / SRP2006 (e.g. Info / Display).
- Only functions that are available on your original remote control can be used for operating your devices with the universal remote controls.

- 1  Setup light. Lights up when a remote control command is being sent, when you just selected a device and when the remote control is in setup mode.
- 2  selects available source inputs (antenna, cable, etc.).
- 3  device selection buttons. Select the device to be operated.



- 4  electronic program guide.
-  menu on / off.
-  on-screen channel information.
-  exits / clears on-screen menu displays.
-     cursor up, down, left, right in a menu.
-  confirms your selection.

A, B, C, D..... Context sensitive buttons, ordered following the requirements for cable boxes.
 A - Yellow, B - Blue, C - Red, D - Green.



+VOL - adjusts TV volume.
MUTE mutes TV sound.
↶ previous program / Last / Back.
+ CH - next / previous channel.



⏮ rewind.
▶ play.
⏭ fast forward.
■ stop.
● record.
⏸ pause.
▼P ▲P previous (▼P) / next (▲P) page / track in various modes.

👍 / 👎 set your Thumb ratings.
 7 **ENTER** used after direct channel selection. some devices require ENTER to be pressed after channel selection.

(-) selects between one and two-figure channel numbers.

8 **1 2 3** digit buttons for direct channel / track selection.
4 5 6
7 8 9
0

9 **POWER** **⏻** switches the selected device on / off.

3.2 Resetting a button to its original function

If an improved button (see chapter 2.2.2) still does not function as expected, you can always reset the button to its original function.

1 In the current device mode, keep digit buttons **1** and **6** **pressed simultaneously for 5 seconds**, until the red Setup light **Ⓢ** lights up.



- The remote control is now in setup mode.

2 Press digit buttons **9**, **9**, and **6**, in that order.

- After each button press the red Setup light **Ⓢ** blinks once.



3 Press the button that you wish to reset **twice**. E.g. the **▶▶** button.

- After each button press the red Setup light **Ⓢ** blinks once.
- The red Setup light **Ⓢ** will blink one more time to confirm that the button was successfully reset to its original function.



Note

For some TV brands / types, the **POWER** **⏻** button will only turn off the TV. You will have to press a digit button (direct channel selection) to turn on the TV again.

4 Service and support

4.1 Frequently asked questions

In this chapter you will find answers to the most frequently asked questions about your universal remote controls.

4.1.1 Setup

I cannot enter setup mode.

Battery level too low or battery lifetime came to an end.

- Replace the batteries. See chapter 2.1. After replacing the batteries, test if the remote control still operates your devices. If it does not, you have to set up the remote control again. For this refer to chapter 2.2.

The brand code for my device is missing in the 'Shortlist of brands' in the Quick Start Guide.

The 'Shortlist of brands' only mentions the most common TV, DVD, CBL/SAT, DVR and VCR brands.

- You will find a complete brand list on page 18-30 of this user manual.
- Use '9999' as 4-digit code in case you cannot find your brand in the complete brand list. Note that using '9999' may result in a long setup (up to 15 minutes).

My TV switches OFF in step 4 but does not switch ON again in step 5.

TVs of some brands (e.g. Panasonic) only switch ON after a long press on one of the digit buttons. After a long button press in setup mode the remote control will start trying to improve the button (see chapter 2.2.2) instead of switching ON the TV.

- In this case, switch ON the TV manually or use the original remote control for this. Continue with step 6. After successfully completing setup, the remote control will switch ON the TV with a long button press on one of the digit buttons, just as your original remote control.

After setup, not all buttons work as expected.

- Try improving the button(s). See chapter 2.2.2.

How do I set up the remote control for combo devices (TV / VCR, TV / DVD, DVD / VCR, etc)?

Some combo devices require you to set up two different device selection buttons to control both parts of the combo device. For example, if you have a TV / DVD combo, you might need to set up the remote control for both TV and DVD to operate your TV / DVD combo.

4.1.2 Operation

The remote control does not wake up anymore.

Battery level too low or battery lifetime came to an end.

- Replace the batteries. See chapter 2.1. After replacing the batteries, test if the remote control still operates your devices. If it does not, you have to set up the remote control again. For this refer to chapter 2.2.

The device I want to operate does not respond at all / does not respond to all of the button commands.

- Check if the buttons you press are available on the original remote control of the device.
- Try improving buttons. See chapter 2.2.2.

Wrong code selected during setup.

- Set up the remote control again for the device. Always test if the device responds, before leaving setup mode.

It may be that the buttons that you are trying to use have a different naming on the original remote control.

- Try out all buttons to find the one(s) you need.

4.1.3 Batteries

Will my settings be deleted when I replace the batteries?

No. All user settings will be retained in the remote control memory for 5 minutes.



Warning

The batteries should not be exposed to excessive heat such as sunshine, fire or the like.

4.2 Need help?

We advise you to first read this user manual carefully. It is provided to help you set up and use the remote control.

If, however, you require extra information or have additional questions about setup, usage, spare parts, warranty, etc. of the universal remote controls, you can always contact us.

When calling our helpline, make sure to have the SRP2003 and / or SRP2006 at hand when you call, so that our operators can help you determine whether the universal remote control(s) is / are working properly.

You will find our contact details at the end of this user manual.

The model numbers of your Philips universal remote controls are SRP2003/27 and SRP2006/27. The model number of the twinpack is SRC2063/27.

Date of purchase:

...../...../.....

(day/month/year)

For **online support** go to:

www.philips.com/welcome.

- Click 'Support' and follow the on-screen instructions.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.



Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Caution

User changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Helpline

Country

Phone number

United States of America /
Canada

001-888-744-5477

Notice for Canada

This class B digital apparatus complies with Canadian ICES-003.

888.....0006 (DB1)	Amplivision...0138	Bush.....0445
A	Ampro.....0139	Byd:sign.....0448
A.R. Systems.0012	Amstrad0140	C
ABC.....0013	AMTC.....4015 (DB1)	Cable Star.....0454
Abex0014	Amtron.....0141	Cabletenna...0456
ABS.....0016	AMW.....0143	Cableview.....0458
Accele Vision 4194	Anam0146	Cablevision ...4238
Access HD... 3554	Anam National	Caihong.....0462
Accurian.....00220147	Caixing.....4093 (DB1)
Acer.....0028	Anglo0151	California Audio
Acura.....0036	Anitech0154	Labs.....0467
ADC.....0040 (DB1)	Ansonic.....0156	Calix.....0468
Addison.....0043	Antronix.....0159	Candle.....0480
Adelphia.....4195	AOC.....0165	Canon.....0481
Admiral.....0046	Aolinpiya.....4089 (DB1)	Capsonic.....0486 (DB1)
Advent0054	Apache.....0169	Captive Works
Adventura.....0055	Apex36910487
Adyson.....0058	Apex Digital.0170	Carad.....0488
Agashi.....0063	Apple0172	Carena.....0489
Agazi.....3522 (DB1)	Arcam.....0179	Carnivale.....0491
AGB.....0064	Archer0180	Carrefour.....0492
Aiko0069	Archos.....0181	Carver.....0494
Aim0070	Ardem.....0184	Cascade.....0496
Aiwa0072	Aristona.....0192	Casio.....0499
Akai.....0074	Arrgo0197	Catha4094
Akiba.....0078	Arris.....4931 (DB1)	Cathay0501
Akira.....0079 (DB1)	Artec.....4016	CCE.....0504
Akito.....0082	Asberg.....0205	Celebrity.....0509
Akura0083	Asha.....0209	Celera.....0510
Alaron.....0085	Aspire4233	Centurion.....0520
Alba0086	Astar.....0218	Century.....0521
Albatron.....0087	Asuka0227	CGE.....0523
Alco0092	AT&T3453	Changcheng..0526
Alienware.....0099	Atlantic.....0233	Changfei.....0527
Allegro.....0103	Atori.....0237	Changfeng...0528 (DB1)
Alleron0104	Audio Dynamics	Changhai.....0529
Allorgan.....01050248	Changhong...0530
Allstar.....0108	Audiosonic...0264	Channel Master
Alpha Digital 4014	Audioton02660531
AlphaStar.....0113	Audiovox.....0268	Chaparral.....0533
Alpine0114	Autovox0280	Ching Tai.....0541
America Action	Aventura0287	Chun Yun0545
.....0123	Awa0296	Chunfeng.....0546
American High	Axion0299	Chung Hsin...0547
.....0125		Chunlan.....4097 (DB1)
Americast.....0127		Chunsun.....0549
Amphion Media		Cimline.....0552
Works.....0135		CineVision...0562
	B	
	Baihua.....4092 (DB1)	
	Baird0311	
	Bang & Olufsen	
0314	
	Baohuashi0316 (DB1)	
	Basic Line.....0325	
	Bastide.....0327	
	Baur0331	
	Bazin0335	
	BBT0338	
	Beaumark.....0340	
	Beijing0345	
	Beko0346	
	Belcor0348	
	BELL4376 (DB1)	
	Bell & Howell	
0350	
	Bell ExpressVu	
0352 (DB1)	
	Bell South.....0353	
	BenQ0359	
	Beon.....0361	
	Best.....0364	
	Bestar.....0368	
	Bestar-Daewoo	
0369	
	Binatone.....0378	
	Black Star.....0386	
	Blacktron.....3526	
	Blackway.....0388	
	Blaupunkt.....0390	
	Blue Parade..0394	
	Blue Sky.....0395	
	Blue Star.....0396	
	Bondstec.....0403	
	Boots.....0405	
	BOSS.....4197	
	BPL.....0413	
	Bradford.....0414	
	Brandt.....0416	
	Brillian.....0422	
	Brinkmann....0423	
	Brionvega.....0424	
	Britannia0425	
	Brockwood...0430	
	Broksonic.....0432	
	BskyB.....0436	
	BTC0439	

Citizen.....0567	Dansai.....0699	E	Fenner.....0994
City.....0569	Dantax.....0702	Eastern.....0859	Ferguson.....0996
Clarion.....0575	Davidson.....4202	ECHOSPHERE	Fidelity.....0998
Clarivox.....0576	Dawa.....07074396 (DB1)	Filsai.....1000
Clatronic.....0581	Daytron.....0710	Echostar.....0866	Finlandia.....1003
Clearmaster..0583	DBX.....0712	Eclipse.....0867	Finlux.....1004
ClearMax.....0584	Decca.....0718	Eiki.....0874	Firstar.....1007
CMS.....0590	Deitron.....0722	Elbe.....0880	Firstline.....1008
CMS Hightec 0591	Dell.....0725	Elbe-Sharp...3529	Fisher.....1009
Coby.....0597	Denon.....0731	Elcit.....0883	Flint.....1014
Colortyme...0601	Denver.....0733	Electroband..0888	FNR.....1016
Colour Voice.0602	Desay.....0737	Electrograph..0889	Focus.....1017
Colt.....0603	Desmet.....0738	Electrohome.0890	Formenti.....1023
Comcast.....3456	Diamant.....0746	Electroponic	Formenti-Phoenix
Commercial	Diamond.....074708931024
Solutions.....0615	Diamond Vision	Elektra.....0896	Fraba.....1030
Comtronics..06230748	Element.....3477	Friac.....1040
Concerto.....0625	Digatron.....0751	ELG.....0900	Frontech.....1042
Concorde.....0626	Digi.....0754	Elin.....0902	Fuji.....1047
Condor.....0627	Digiline.....0759	Elite.....0903	Fujitsu.....1052
Conrowa.....0634	Digital Stream	Elmak.....0907 (DB1)	Fujitsu General
Contec.....06353809	Elta.....09101053
Contec/Cony4199	Dimensia.....3569	Emerson.....0917	Funai.....1056
Coolmax.....0642	Director.....0793	Emperor.....0921	Furi.....1057
Coolsat.....0643	DirecTV.....0794	Emprex.....0922	FUTECH.....3960 (DB1)
Coship.....0646	Dish Network	Enterprise.....0931	Futuretech.....1064
Cosmel.....0647	System.....0799	Envision.....0933	
COX.....4200	Dishpro.....0800	Epson.....0937	G
Craig.....0650	Disney.....0803	Erres.....0942	Galaxi.....1068
Crosley.....0655	Dixi.....0807	ESA.....0943	Galaxis.....1069
Crossdigital...0656	Dongda.....0820	ESC.....0945	Garrard.....1075
Crown.....0658	Donghai.....0821	Ether.....0948	Gateway.....1076
CS Electronics	Drake.....0825	Etron.....0949	GBC.....1078
.....0663	Drean.....0832	Eurofeel.....0954	GC Electronics
CTC.....0664	DSE.....0833	EuroLine.....0955 (DB1)1080
CTX.....0665	DTS.....0837	Euroman.....0956	GE.....1081
Curtis Mathes	Dual.....0838	Europa.....0957	GEC.....1083
.....0667	Dual-Tec.....3528	Europhon.....0959	Gehua.....1086
CXC.....0670	Dumont.....0840	Everquest.....0971	Geloso.....1087
CyberHome..0672	Durabrand....0842	Expressvu.....0977	Gemini.....1089
Cybernex.....0673	Dux.....0843	Exquisit.....0978	General Instrument
CyberPower..0674	DVD2000.....0844	1093
Cybertron.....0675	D-Vision.....0684	F	General Technic
Cytron.....0680	Dwin.....0848	Fagor Life.....41021095
	Dynatech.....0854	Feilang.....0990	Genexxa.....1097
D	Dynatron.....0855	Feilu.....0991	GFM.....3820
Daeryung.....0691	Dynex.....3476	Feiyan.....0992 (DB1)	Giant.....1113
Daewoo.....0692		Feiyue.....0993	Gibraltar.....1114
Danichi.....3914		Fenmenti.....4103	Go Video.....1126

GOI.....	1130	Hisawa.....	1247	InFocus.....	1353	Kanghua.....	1477
GoldHand	1136	Hisense	1249	Ingelen.....	1354	Kangli.....	1478 (DB1)
Goldline.....	1138	Hitachi.....	1251	Ingersol	1355	Kangyi.....	1479 (DB1)
GoldStar.....	1140	Hitachi Fujian	1252	Initial.....	1356	Karcher.....	1484
Goodmans.....	1142	Hiteker.....	1255	Inno Hit.....	1358	Kawa.....	1487
Goodmind	1143	Hitsu.....	1257	Innova.....	1359	Kawasaki.....	1488
GPM.....	1149	Hoeher.....	1262	Innovation	1360	Kawasho.....	1489
Gradiente.....	1151	Hongmei.....	1272	Insignia.....	1368	Kaypani.....	1490
Graetz.....	1152	Hongyan.....	1274 (DB1)	Instant Replay		KEC.....	1496
Granada.....	1154	Hornophon....	1277	3580	Kendo.....	1500
Grandin.....	1156	Hoshai.....	1278	Integra.....	1370	Kenwood.....	1507
Greenhill	1157	Howard		Inteq.....	1373	KIC.....	1512
Gronic.....	1160	Computers....	1281	Interbuy.....	1376	Kingsley.....	1520
Grundig.....	1162	HP.....	1283	Interfunk.....	1377	Kioto.....	1523
Grunpy.....	1165	HTS.....	1285	Internal.....	1379	Kiton.....	1525
H		Huafa.....	1287	International..	1380	KLH.....	1529
Haier.....	1175	Huanghaimei.	1288	Intervision.....	1386	Kloss Novabeam	
Haihong.....	1176	Huanghe.....	1289	IR.....	4110	4210
Haiyan.....	1177 (DB1)	Huanglong....	1290	Irradio.....	1396	Kneissel	1535
Halifax.....	1179	Huangshan	1291	Isukai.....	1402	Kodak.....	1540
Hallmark.....	1180	Huanyu	1292	iSymphony	3755	Kolin.....	1541
Hamlin.....	1182	Huaqiang.....	1293 (DB1)	ITC.....	1404	Kolster.....	1543
Hampton.....	1183	Huari.....	1294	ITS.....	1405	Kongque.....	1545 (DB1)
Hankook.....	1188	Huges.....	4205	ITT.....	1406	Konig.....	1547
Hanseatic.....	1190	Hughes Network		ITV.....	1408	Konka.....	1548
Hantarex.....	1192	Systems.....	1296	J		Korpel.....	1552
Hantor.....	1193	Humax.....	1298	Janeil.....	1414	Korting.....	1554
Harley Davidson		Hush.....	1304	Jasco.....	1415	Kosmos.....	1557
.....	1197	Hygashi.....	1308	JBL.....	1420	Koss.....	1558
Harman/Kardon		Hyper.....	1309	JC Penney.....	4208	KTV.....	1572
.....	1198	Hypson.....	1312	JCB.....	1421	Kuaile.....	1573 (DB1)
Harvard.....	1202	Hytex.....	1314	JCL.....	4209	Kunlun.....	1578 (DB1)
Harwood.....	1204	Hyundai.....	1315	Jean.....	1424	Kyoshu.....	1583
Hauppauge....	1206	I		Jensen.....	1429	Kyoto.....	1585
Havermy.....	1208	Iberia.....	1320	Jerrold.....	1431	L	
HCM.....	1210	iBUYPOWER		Jiahua.....	1435 (DB1)	L&S Electronic	
Headquarter.	1214	1322	JiaLiCai.....	1436 (DB1)	1588
Hello Kitty.....	1221	ICE.....	1324	Jinque.....	1440 (DB1)	Landel.....	1593
Hema.....	1222	ICeS.....	1325	Jinta.....	1441 (DB1)	Lasonic.....	1600
Hemmermann		Illico.....	4206	Jinxing.....	1442	Layco.....	4117
.....	1223	iLo.....	1341	Juhua.....	1461 (DB1)	Lecson.....	1606
Hewlett Packard		iLuv.....	4234	JVC.....	1464	Lenco.....	1615
.....	1229	Ima.....	1342	jWin.....	1465	Lenoir.....	1617
Higashi.....	1234	Imperial.....	1346	K		Lenoxx.....	1618
Highline.....	1236	Imperial Crown		Kaige.....	1470 (DB1)	Lesa.....	1622
Hikona.....	1237	1347 (DB1)	Kaisui.....	1471	Lexicon.....	1625
HiLine.....	3533	Indiana.....	1350	Kamp.....	1475	Leyco.....	1627
Hinari.....	1243	Infinity.....	1352			LG.....	1628

LG/Goldstar...3536 (DB1)	Medison.....1788	N	Oak.....2059
Liesenk.....3537 (DB1)	MegaCable....4211	NAD.....1926	Okana.....4122
Liesenk & Tter1630	Megapower...1791	Naiko.....1930	Okano.....2065
Liesenkotter...1631	Megatron.....1795	Nakamichi...1932	Olevia.....2067
Life.....3538 (DB1)	MEI.....1796	Nakamura.....1933	Olympus.....2071
Lifetec.....1633	Meile.....1797 (DB1)	Nanbao.....1934 (DB1)	Onimax.....2082
Linksys.....1640	MeiShi.....4118 (DB1)	Nansheng.....1935 (DB1)	Onkyo.....2085
Linsay.....1642	Melectronic...3654	National Panasonic4661	Onwa.....2087
Liquid Video..1644	Memorex.....1800	NEC.....1950	Opera.....2090
LiteOn.....1645	Memphis.....1802	Neckermann.1951	Oppo.....2092
Lloyd's.....1648	Mercury.....1804	NEI.....1952	Optimus.....2095
Local India TV1653	Metz.....1810	Nesa.....1959	Optoma.....2097
Loewe.....1660	MGA.....1811	Nesco.....1960	Optonica.....2099
Loewe Opta.3540	MGN Technology1812	Net Brazil.....1962	Orbit.....2103
Logik.....1661	MicroGEM....4024	Netsat.....1966	Orion.....2111
Longjiang.....1664 (DB1)	Micromaxx...1822	NetTV.....1967	Oritron.....2112
Luma.....1674	Microsoft.....1826	Neufunk.....1970	Orline.....2113
Lumatron.....1676	Microstar.....1827 (DB1)	New Tech.....1979	Ormond.....2114 (DB1)
Lux May.....1680	Midland.....1831	New World...1980	Orsowe.....2116
Luxman.....1682	Minato.....1835	Newave.....1981	Osaki.....2118
Luxor.....1683	Mind.....1837	Next Base.....1983	Osio.....2121
LXI.....1686	Minerva.....1838	Next Level....1984	Oso.....2122
M	Minoka.....1840	Nexus.....1989	Osume.....2123
M & S.....1687	Minolta.....1841	NexxTech.....1990	Otto Versand2126
Madison.....1698	Mintek.....1845	Nicamagic.....1994	P
Magnadyne....1702	Minutz.....1847	Nikkai.....1998	Pace.....2134
Magnafon.....1703	Mitsubishi.....1855	Nikko.....2000	Pacific.....2135
Magnasonic...1704	Mivar.....1857	Niveus Media2012	Pael.....2140
Magnavox.....1706	MoDeng.....4120 (DB1)	Noblex.....2013	Palladium.....2145
Magnin.....1708	Monivision.....1872	Noblisko.....2014	Palsonic.....2147
Magnum.....1709	Montgomery Ward.....4212	Nokia.....2017	Panama.....2149
Majestic.....1713	Morgans.....3970	Norcent.....2020	Panasonic.....2153
Mandor.....1717 (DB1)	Motorola.....1878	Nordic.....2021	Panavision.....2154
Manesth.....1718	Movie Time...1880	Nordmende..2022	Panda.....2155
Manhattan.....1719	MTC.....1889	Nordvision...3543 (DB1)	Pansat.....2158
Marantz.....1724	MTLogic.....1892	Normerel.....2024	Panther.....2160
Mark.....1731	Mudan.....1896 (DB1)	Northgate.....2027	Paragon.....2161
Marta.....1735	Multistandard1904	Noshi.....2030	Pathe Cinema2168
Masuda.....1744	Multisystem...4121 (DB1)	Nova Vision...2032	Pausa.....2171
Matsui.....1750	Multitec.....1906	Novaplex.....2034	Paysat.....2173
Matsushita....1751	Multitech.....1907	Novatronic...2035	PCT.....4213
Maxent.....1757	Multivision....1909	NSC.....2042	Penney.....2182
Media Center PC1777	Murphy.....1911	NTC.....2045	Pentax.....2183
Mediator.....1784	Musikland.....1915		Perdio.....2185
Medion.....1787			Perfekt.....2186
			Philco.....2192

- Philharmonic2194
 Philips.....2195
 Philips Magnavox3715
 Phoenix.....2199
 Phonola.....2201
 Phonotrend...2202
 Pilot.....2207
 Pioneer2212
 Pionier.....2213
 Plantron.....2219
 Plasmsync.....4230
 Playsonic.....2224
 Polaroid.....2230
 Polk Audio.....2232
 Poppy.....2236
 Popular Mechanics2237
 Portland.....2238
 Powerpoint...2241
 Prandoni Prince4125
 Precision.....2244
 Prelude.....2247
 Priceclub2252
 Prima.....2253
 Primestar.....2257
 Princeton2258
 Prinz.....2260
 Prism2261
 Proceed.....2267
 Profekt.....4126
 Profex.....2269
 Profilo2272 (DB1)
 Profitronic.....2273
 Proline.....2274
 Proscan.....2279
 Prosonic2282
 Protech2284
 Proton.....2288
 Protron2289
 Proview.....2290
 ProVision2291
 Pulsar.....2296
 Pye.....2302
 Pymi.....2304
- Q**
 Qingdao2308 (DB1)
 Quarter.....2318
 Quartz2319
 Quasar2320
 Quelle.....2322
 Questa2324
 Qwestar2326
- R**
 Radialva.....2329
 Radio4128
 Radio Shack/
 Realistic.....4214
 Radiola2330
 Radiomarelli..2331
 RadioShack...2333
 Radiotone.....2334
 Radix2335
 Randex.....2343
 RCA2351
 Realistic.....2354
 Recor2359
 Recoton2361
 Rectiligne2362
 Redstar2366
 Reflex.....2368
 Regal.....2370
 Regency.....2371
 Regent.....2372
 Rembrandt...2375
 Reoc.....2379
 ReplayTV2380
 Revox.....2383
 Rex.....2385
 RFT.....2386
 Rhapsody.....2387
 Ricavision2388
 Rio.....2393
 R-Line2327
 Roadstar.....2398
 Rogers.....4215
 Rotel.....2414
 Rowa.....2416
 Runco2423
- S**
 Saba.....2429
 SageTV.....4981 (DB1)
 Saisho.....2437
 Saivod.....2439
 Salora.....2443
 Sambers2445
 Sampo2446
 Samsung.....2448
 Sandra2454
 Sanjian2455 (DB1)
 Sanky2456
 Sansui.....2458
 Sanyo2462
 Sanyuan2464
 SBR.....2492
 Sceptre.....2498
 Schaub Lorenz2500
 Schneider.....2501
 Scientific Atlanta2503
 Scimitsu.....2505
 Scott.....2506
 Scotch.....2508
 Sears.....2514
 SEG.....2522
 SEI.....2524
 Sei-Sinudyne..2525
 Seleco2528
 Sencora.....2531
 Sensory Science2533
 Sentra2534
 Serino2539
 Shancha2546 (DB1)
 Shanghai2547
 Shaofeng2549
 Sharp.....2550
 Sharper Image2551
 Shen Ying2552
 Shencai.....2553
 Sheng Chai...3922
 Shenyang.....2555
 Sherwood.....2557
 Shinco.....2560
 Shinsonic.....2562
 Shintoshi.....2564
 Shivaki.....2567
 Shogun2568
 Siam.....2572
 Siarem2573
 Siemens.....2574
 Siera.....2576
 Sierra.....3549 (DB1)
 Sigma Designs2579
 Signal2581
 Signature2582
 Silva2591
 Silva Schneider2592
 Silver.....2594
 Simpson.....2598
 Sindyne4510
 Singer2599
 Sinudyne.....2601 (DB1)
 SKY.....2610
 Skygiant.....2618
 Skyworth2631 (DB1)
 SL Marx.....2633
 Sogera2649
 Solavox.....2654
 Sonawa2663
 Sonic Blue.....2667
 Sonicview3954
 Soniko.....2669
 Sonitron.....2671
 Sonneclair...2673
 Sonoko.....2675
 Sontec2677
 Sony.....2679
 Sound & Vision2680
 Soundesign ...2684
 Soundwave...2689
 Sowa.....2691
 Squareview...2703
 Srypton.....4138
 SSS.....2708
 Stack.....4218
 Standard.....2713
 Standard
 Components 2714
 Star Choice...2716
 Starcom.....2722
 Stargate.....2723

Starlite.....	2728	TCM.....	2857 (DB1)	Tokyo.....	3004	V	
Starquest.....	2732	Teac.....	2860	Tomashi.....	3006	V2.....	3128
StarSight.....	2734	Teachimagen.....	4140	Tongguang.....	3008 (DB1)	Vector.....	3136
Stenway.....	2739	Tec.....	2861	Torx.....	3020	Vector Research	
Strato.....	2745	Tech Line.....	2863	Toshiba.....	3021	3137
STS.....	2749	Technema.....	2866	Totevision.....	3024	Venturer.....	3143
STS1.....	4219	Technica.....	2868	Touch.....	3025	Verizon.....	3146
STS2.....	4220	Technics.....	2869	Towada.....	3028	Vestel.....	3148
STS3.....	4221	Technika.....	2870	Toyoda.....	3030	Vexa.....	3149
STS4.....	4222	Techview.....	2883	Trakton.....	3036	Victor.....	3155
Studio Experience		Techwood.....	2884	Trans Continens		Video Concepts	
.....	2750	Teco.....	2886	3037	3157
Stylandia.....	2752	Tedelex.....	2889	Trans PX.....	3038	Videologic.....	3165
Sungale.....	2761	Teknika.....	2895	Transfec.....	4143	Videologique	3166
Sunkai.....	2762	TeleCaption... ..	2902	Transonic.....	3041	Videosonic.....	3171
Sunstar.....	2768	Telecor.....	2910	Transtec.....	3042	VideoSystem.....	3172
Sunwood.....	2772	Telefunken.....	2914	Tredex.....	3045	Videotechnic.....	3173
Supercable.....	2778	Telefusion.....	2915	Trident.....	3054	Videotron.....	3175
Superla.....	2782	Telegazi.....	2917	Tristar.....	3057	Vidikron.....	3178
Supermax.....	2783	Telemeister... ..	2924	Triumph.....	3058	Vidtech.....	3179
Superscan.....	2786	Telesonic.....	2930	TruTech.....	3467	Viewmaster... ..	3182
SuperTech.....	2789	Telestar.....	2931	TS.....	3063	ViewSat.....	3185
Supervision... ..	2791	Teletech.....	2934	Tuntex.....	3069	Viewsonic.....	3186
Supra.....	2792	Teleton.....	2935	Tusa.....	3073	Viewstar.....	3187
Supre-Macy.. ..	2794	Televideo.....	2938	TV86.....	3076	Viking.....	3188
Supreme.....	2795	Television.....	2939	TVView.....	3079	Villain.....	3189
Sutron.....	2798	Tennessee.....	2952	TVS.....	3081	Viore.....	3192
SVA.....	2800	Tensai.....	2954			Visco.....	4232
Sydney.....	2808	Tenson.....	2955	U		Visiola.....	3197
Sylvania.....	2809	Terapin.....	2958	Uher.....	3089	Vision.....	3198
Symphonic.....	2810	Tevion.....	2962	UltimateTV... ..	3091	Vizio.....	3211
Synco.....	2811	Texet.....	2963	Ultravox.....	3095	Vocopro.....	3213
Syntax.....	2814	Texscan.....	2965	Unic Line.....	3100	Voodoo.....	3215
Syntax-Brilliant		TFC.....	2967	Uniden.....	3101	Voom.....	3216
.....	4231	Theta Digital.....	2970	Unika.....	3102	Vortec.....	3217
Sysline.....	2815	Thomas.....	2971	Unitech.....	3105	Vortex View.. ..	3218
Systemax.....	2817	Thomson.....	2972	United.....	3106	Voxson.....	3220
Sytong.....	2820	Thorn.....	2974	United Artists			
		Thorn-Ferguson		3107	W	
T		2976 (DB1)	United Cable.....	3108	Waltham.....	3230
Tacico.....	2823	Time Warner.....	3518	Universal.....	3113	Wards.....	3231
Tagar Systems		Timeless.....	2985	Universum.....	3115	Watson.....	3233
.....	2831	Tivax.....	3956	Univox.....	3116	Watt Radio... ..	3234
Tai Wah.....	4139 (DB1)	Tivo.....	2991	Urban Concepts		Waycon.....	3237
Taishan.....	2835	TMK.....	2994	3121	Wega.....	3238
Tandy.....	2843	TNCi.....	2996	US Digital.....	3122	Wegavox.....	3239
Tashiko.....	2850	Tobo.....	2999 (DB1)	US Electronics		Weltblick.....	3245
Tatung.....	2852	Tocom.....	3000	3123	Westinghouse	
TCL.....	2856 (DB1)	Tokai.....	3001	US Logic.....	3124	3249

Wharfedale...3255
 White Westinghouse
3258
 Windstar3266
 Winegard.....3268

X
 Xbox3295
 Xiahua3299
 Xiangyang.....3301 (DB1)
 Xiangyu.....3302
 Xihu3303 (DB1)
 Xinaghai.....3304 (DB1)
 Xingfu3305
 Xinghai3306
 XR-10003316
 Xrypton.....3317
 Xuelian.....3320 (DB1)

Y
 Yamaha3326
 Yamishi3328
 Yapshe3329
 Yokan3335
 Yoko.....3336
 Yorx3340
 Yuhang.....3345

Z
 Zanussi.....3349
 Zenith.....3356
 Zentech.....4031
 Zentek.....3361
 ZhuHai.....3364
 ZT Group3370

(DB1) Brands only available from version DB1 onwards. You can find the DB version on the sticker inside the battery compartment.



EN Information to the consumer

Compliance with EMF

Koninklijke Philips Electronics N.V. manufactures and sells many products targeted at consumers, which, like any electronic apparatus, in general have the ability to emit and receive electromagnetic signals.

One of Philips' leading Business Principles is to take all necessary health and safety measures for our products, to comply with all applicable legal requirements and to stay well within the EMF standards applicable at the time of producing the products.

Philips is committed to develop, produce and market products that cause no adverse health effects. Philips confirms that if its products are handled properly for their intended use, they are safe to use according to scientific evidence available today.

Philips plays an active role in the development of international EMF and safety standards, enabling Philips to anticipate further developments in standardization for early integration in its products.

Recycling and disposal

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC:



Never dispose of your product with other household waste. Please inform yourself about the local separate collection system for electrical and electronic products. Please act according to your local rules and do not dispose of your old products with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.



© 2010 Koninklijke Philips Electronics N.V.

All rights reserved. Reproduction in whole or in part is prohibited without the prior written consent of the copyright owner.

The information presented in this document does not form part of any quotation or contract, is believed to be accurate and reliable and may be changed without notice. No liability will be accepted by the publisher for any consequence of its use. Publication there of does not convey nor imply any license under patent- or other industrial or intellectual property rights.

Document order number: 3139 235 5308 4

November 2011

www.philips.com

RTP/4811