

## Introduction:

Philips strives to continually bring you the best experience from our products. To obtain the optimal playback and latest features, you are highly recommended to update the firmware of your player.

### Preparation for firmware update:


1. Ensure your Airplay speaker is connected to the same network as your Apple device.
2. Turn on the speaker.
3. Wait until there is a beep sound and the LED indication turns solid green

If your speaker is not setup yet, please follow below steps:

1. Power on your speaker, if you hear a beep sound or find the LED is in green color after 1 minute, please go to **step 8** directly. Otherwise, please go to point 2.

2-1. Connect your iPod touch/iPhone/iPad to your home Wi-Fi network.

3-2. Dock your iPod/iPhone/iPad onto the unit.



4-3. Press  on the front panel of the unit

5-4. The following dialog box is displayed:



6-5. Tap “Allow” to share your Wi-Fi settings with your device. After a while, the LED turns solid green with a “beep” sound.

7-6. Your speaker is connected to your existing Wi-Fi network successfully.

*For update via App:*


1. Launch the SoundStudio  App

Formatted: Underline

2. On the App, there will be a prompt of choosing appropriated speaker. Select your speaker.



3. After selected the speaker, select "Settings"



4. Tap "Firmware upgrade" and "Next" in below screen:

Cancel Firmware upgrade Next

Please make sure that your phone is docked to speaker and press next.

5. There will be a prompt if a new firmware is found, then tap "Next"

Cancel Firmware upgrade Next

Upgrade is available.

Please make sure that you are connected to the speaker during the firmware upgrade.

Current version: 9575.49.1

Upgrade version: Vs9575.53.1000

6. Following the on screen instructions to complete the upgrade. It will take around 5 mins

If you cannot upgrade via SoundStudio App, please upgrade your speaker with computer.

*For update via computer:*

- Your device is connected to your Wi-Fi network as same as your computer

## Update Procedure:

1. Download the latest firmware

2. Upgrade your player with PC

3. Confirm upgrade successfulness

### Step 1: Download the latest firmware

- Click on the Download icon at the top of the screen to download the new firmware package with extension .fw to your computer.




**Note:** Please DO NOT rename either the folder name or the file name in the folder to avoid an update corruption.

### Step 2: Update your speaker with computer

~~8-7. Power on your speaker, if you hear a beep sound or find the LED is in green color after 1 minute, please go to step 8 directly. Otherwise, please go to point 2.~~

~~9-8. Connect your iPod touch/iPhone/iPad to your home Wi-Fi network.~~

~~10-9. Dock your iPod/iPhone/iPad onto the unit.~~



~~11-10. Press  on the front panel of the unit~~

~~12-11. The following dialog box is displayed:~~




13.12. ~~Tap "Allow" to share your Wi-Fi settings with your device. After a while, the LED turns solid green with a "beep" sound.~~


14.13. ~~Your speaker is connected to your existing Wi-Fi network successfully.~~

**On the computer**

15. 1. Start **Safari browser** in your computer.

**Note: Make sure your computer and the speaker is in the same network**

16. 2. Click the open-book icon  in the Safari bookmarks bar, and then select **Bonjour** in the Collections list.



**Formatted:** Font: +Headings (Cambria)

**Formatted:** Normal, No bullets or numbering

**Formatted:** Font: +Headings (Cambria), Bold

**Formatted:** Font: +Headings (Cambria)

**Formatted:** Font: +Headings (Cambria), Bold, Font color: Red

**Formatted:** Font: +Headings (Cambria)


**Formatted:** Font: +Headings (Cambria)

**Formatted:** Font: +Headings (Cambria)

**Formatted:** Normal, No bullets or numbering

**Formatted:** Font: +Headings (Cambria)

17. 3. Click on **Philips\_SoundSphere** XXXXXX



Formatted: Font: +Headings (Cambria)

Formatted: Font: +Headings (Cambria), Bold

Formatted: Font: +Headings (Cambria)

Formatted: Font: +Headings (Cambria)

18. 4. The Philips Fidelio Airplay Webpage would be launched. **DO NOT click on anything.**



Formatted: Font: +Headings (Cambria)

Formatted: Font: +Headings (Cambria)

19. 5. **Wait** until the following page (Philips Fidelio Airplay update page) is launched. Then click **"Firmware Update"**.

Note: If there is a lot of interference in the environment, there would be delay before the web pages refreshes. This refresh can take up to 5mins.



Formatted: Font: Not Bold

Formatted: Font: +Headings (Cambria)

Formatted: Font: +Headings (Cambria)

20. 6. Click on **Choose file.**

Browse for **.fw** file (downloaded in **Step 1 Download the latest firmware**) and click "upload".



Formatted: Normal, No bullets or numbering

Formatted: Font: +Headings (Cambria)

21. 7. Check the current and new firmware version and then click **"OK"** to proceed

Formatted: Normal, No bullets or numbering

Formatted: Font: +Headings (Cambria)



New firmware version

Current firmware version

~~22.~~ 8. Once completed, the message “**Upload process finished successfully**” will be shown.

### Step 3: Confirm update successfulness

1. Repeat the Step 2, point ~~81-712~~ to check if current firmware is same as the new one.
2. If the latest firmware has not been installed, repeat ‘**Step 2 Update your player with Computer** and ‘**Step 3 Confirm update successfulness**’.

**Formatted:** Normal, No bullets or numbering

**Formatted:** Font: +Headings (Cambria)