

- 玻璃奶瓶加热消毒后会持续保持高温状态，须使用奶瓶夹取玻璃奶瓶，或等奶瓶冷却后取出，以防烫伤。
- 切勿用金属汤匙搅拌玻璃奶瓶，以防导致细小裂纹。
- 切勿将玻璃奶瓶放入冰箱冷冻室中冷冻。

首次使用之前

- 初次使用前请去除置于奶嘴下的纸质垫片。
- 对产品进行清洁和消毒。
- 为保证卫生，请将其置于沸水中煮 5 分钟。

每次使用前请清洁

- 彻底洗净并冲洗，然后使用飞利浦新安怡消毒锅进行消毒，或在沸水中煮 5 分钟。有关消毒锅的详细信息，请参阅消毒锅用户手册。
- 请勿使用腐蚀性抑菌清洁剂、化学溶液或高浓度洗涤剂。
- 请勿将部件直接放在使用抗菌清洁剂清洁过的物体表面。
- 可用洗碗机清洗 - 食物的颜色可能会使组件变色。

奶嘴


- 每次使用之前，朝各个方向拉拔奶嘴进行检查。
- 若有破损或缺陷，请即丢弃。
- 哺喂宝宝时，请确保使用正确流量的奶嘴。
- 出于卫生考虑，建议您每 3 个月更换一次奶嘴。
- 为保持卫生，请拆开奶瓶并将所有组件存放在干燥的带盖容器中。
- 使奶瓶及其组件远离热源并避免阳光直射，置于消毒剂（消毒溶液）中的时间也不要

超过建议时间。


- 奶嘴分为新生儿流量、慢流量、中流量、快流量和可调流量几种型号。经典系列奶嘴只能与经典系列奶瓶配合使用。
- 要购买附件和备件，请访问 www.shop.philips.com/service 或联系飞利浦经销商。您也可以联系您所在国家/地区的飞利浦客户服务中心。

飞利浦新安怡竭诚为您服务：
中国大陆服务热线：
4008 800 008

Philips AVENT Classic feeding Bottle
飞利浦新安怡经典系列奶瓶



Philips AVENT breast milk container
飞利浦新安怡母乳储存杯



PHILIPS
AVENT

产品 : 飞利浦新安怡宽口径经典玻璃奶瓶
新生儿套装
型号 : SCF647/57
容量 : 奶瓶: 125毫升×1、240毫升×1
奶嘴: 0月+(新生儿流量)×1、
1月+(慢流量)×1
主要材料 : 高硼硅玻璃、聚丙烯(PP)、硅胶
耐热温度 : 瓶身600°C,其他部件110 °C
执行标准 : 奶瓶: GB17762-1999 (卫生安全),
GB19778-2005
奶嘴: GB4806.2-1994
奶瓶盖/螺旋盖: GB9688-1988
保质期 : 5年
检验 : 合格
产地 : 中国江苏丹阳
生产日期 : 见外包装

飞利浦(中国)投资有限公司 上海市天目西路218
号1602-1605
邮编: 200070
全国顾客服务热线: 4008 800 008

PHILIPS
AVENT

产品 : 飞利浦新安怡宽口径经典玻璃奶瓶
8oz/240毫升
型号 : SCF647/17
容量 : 240毫升、奶嘴: 1月+(慢流量)
主要材料 : 高硼硅玻璃、聚丙烯(PP)、硅胶
耐热温度 : 瓶身600°C,其他部件110 °C
执行标准 : 奶瓶: GB17762-1999 (卫生安全),
GB19778-2005
奶嘴: GB4806.2-1994
奶瓶盖/螺旋盖: GB9688-1988
保质期 : 5年
检验 : 合格
产地 : 中国江苏丹阳
生产日期 : 见外包装

飞利浦(中国)投资有限公司 上海市天目西路218
号1602-1605
邮编: 200070
全国顾客服务热线: 4008 800 008

出版日期: 2014-08-05

PHILIPS
AVENT

产品 : 飞利浦新安怡宽口径经典玻璃奶瓶
4oz/125毫升
型号 : SCF645/17
容量 : 125毫升、奶嘴: 0月+(新生儿流量)
主要材料 : 高硼硅玻璃、聚丙烯(PP)、硅胶
耐热温度 : 瓶身600°C,其他部件110 °C
执行标准 : 奶瓶: GB17762-1999 (卫生安全),
GB19778-2005
奶嘴: GB4806.2-1994
奶瓶盖/螺旋盖: GB9688-1988
保质期 : 5年
检验 : 合格
产地 : 中国江苏丹阳
生产日期 : 见外包装

飞利浦(中国)投资有限公司 上海市天目西路218
号1602-1605
邮编: 200070
全国顾客服务热线: 4008 800 008

© 2014 Koninklijke Philips N.V.
4241 210 48501

在以下网站上注册产品并获得
支持: www.philips.com/welcome



SCF645
SCF647

GB User Manual

SC 用户手册

使用产品前请仔细阅读
读本使用说明书
保留备用

PHILIPS
AVENT

EN

For your child's safety and health WARNING!

- Always use this product with adult supervision. After opening, immediately dispose of the product or store it in a place out of babies' reach.
- Never use feeding teats as a soother.
- Continuous and prolonged sipping of fluids will cause tooth decay.
- Always check food temperature before feeding.
- Heating in a microwave oven may produce localised high temperatures. Take extra care when you heat up drinks in a microwave.
- Keep all components not in use out of the reach of children.

- Do not allow children to play with small parts or walk/run while using bottles or cups.
- Do not place in a heated oven.
- To avoid scalding, allow hot liquids to cool before preparing the feeds.
- Drinks other than milk and water, such as fruit juices and flavoured sugary drinks are not recommended. If they are used, they should be well diluted and only used for limited periods, not constantly sipped.
- To ensure the bottle functions correctly and to prevent leakage, always make sure you: remove any debris or residue that may collect around the rim of the bottle before assembly, and avoid over-tightening the bottle screw ring when assembling it onto the bottle.
- Expressed breast milk can be stored in sterilised Philips AVENT bottles/

- containers in the refrigerator for up to 48 hours (not in the door).
- Check the bottle before each use to ensure all components are attached correctly. If you discover any damage, cracks or broken pieces on the bottles are fragile and should be used with care - do not let the baby use the bottle unaided.
- When the glass bottle is wet, handle with extra care to avoid slippage.
- When the surrounding temperature or the temperature of the glass bottle is low, do not immerse the bottle directly into boiling water to prevent cracks to the bottle.
- To avoid cracks, never use iced water to cool the glass bottle. Instead, use running water to cool the bottle, or immerse the bottle in a basin containing an appropriate amount of cold water.

- The glass bottle will remain hot following sterilization. To prevent burns, use the bottle tong to take the bottle or wait until cooling down.
- Do not use metal spoons to stir glass bottles.
- Do not place the glass bottle in the freezer.
- Please read this instructions carefully before using the appliance
- Please keep this instruction book for future reference.

Before first use

- Remove the paper pad under the teat before first use.
- Clean and sterilise the product.
- Place in boiling water for 5 minutes. This is to ensure hygiene.

Clean before each use

- Wash and rinse thoroughly, then sterilise using a Philips AVENT steriliser or boil

- for 5 minutes. Refer to the user manual of the steriliser for more details of the appliance.
- Do not use corrosive antibacterial cleaners, chemical solutions or highly-concentrated detergents with your products.
- Do not place any components on surfaces that have been cleaned with antibacterial agents.
- Dishwasher safe – food colourings may discolour components.

Teats

- Inspect before each use and pull the feeding teat in all directions. Throw away at the first signs of damage or weakness.
- Make sure you use a teat with the correct flow rate when you feed your baby.
- For hygiene reasons, we recommend replacing teats after 3 months.



- For hygiene reasons, remove all components and store in a dry container with a lid.
- Store the bottle and its components away from heat sources and direct sunlight. Do not immerse them in the detergent (sterilising solution) over the recommended time.
- Teats available in newborn, slow, medium, fast and variable flow rates. Only use Classic teats with Classic bottles.
- To buy accessories or spare parts, visit www.shop.philips.com/service or go to your Philips dealer. You can also contact the Philips Consumer Care Center in your country.

Philips AVENT is here to help:
4008 800 008

ZH-S

为了儿童的安全和健康 警告!

- 务必在成人的监督下使用本产品。新产品包装拆卸后请立即丢弃或存放到宝宝接触不到的地方。
- 请勿将奶嘴用作安抚奶嘴。
- 长时间持续吮吸液体可能导致蛀牙。
- 喂食前请务必检查食物的温度。

- 在微波炉中加热可能会产生局部高温。在微波炉中加热饮品时应格外小心。
- 所有不用的部件放置在儿童无法接触到的地方。
- 切勿让儿童玩耍小零件，或让儿童在行走或奔跑时使用奶瓶或杯子。
- 切勿置于发热炉具内。
- 避免烫伤，请等待液体冷却后再哺喂宝宝。
- 建议不要在奶瓶内装入奶或水以外的液体食物，例如果汁和带有味道的含糖饮料。如果确实要使用，请充分稀

- 释这类液体，并尽量缩短使用时间，避免持续啜饮。
- 保证奶瓶功能完好并且没有泄漏，请始终确保：组装前，清除所有聚积在瓶身边缘的碎屑或残留物，将螺旋盖组装到瓶身上时避免拧得过紧。
- 已消毒的飞利浦新安怡奶瓶/储存杯中存储的母乳最多可在冰箱冷藏室内存放 48 小时（不包括放在冰箱门上）。
- 每次使用之前，检查奶瓶，确保各组件已正确组装，如果发现损坏、破裂或碎片碎渣，须立即停止使用奶瓶。

- 玻璃奶瓶属易碎物品，须小心使用，切勿让婴儿自己使用玻璃奶瓶。奶瓶跌落或遭碰撞可能破碎，产生锋利的碎片和碎渣对人体造成伤害。
- 玻璃奶瓶湿漉时，须小心使用以防滑落。
- 气温较低以及玻璃奶瓶本身温度较低时，切勿直接注入沸水，以防奶瓶破裂。
- 切勿用冰水冷却玻璃奶瓶，以防奶瓶破裂。可使用流水冷却或将奶瓶置于装有适量冷水的盆中冷却。

